

## Harsco

www.harscotrack.com

# SERVICE BULLETIN MAINTENANCE OF WAY EQUIPMENT

DATE:	1-7-2004			BULLETIN NO:	03-029
TITLE:	BRAKE CHAMBER CAGING INSPECTION AND REPORTING (BNSF ONLY)				
RATING:	X	<b>DIRECTIVE</b> (Action Is Required)		<b>ALERT</b> (Potential Problem)	
		<b>INFORMATION</b> (Action Is Optional)		<b>PRODUCT IMPROVEMEN</b> (Enhance Product)	Г
PRODUCT SERIES / MODEL: W139A1 Spike Reclaimer BSTA1 Bulk Spike Trailer					

- SERIAL NO: All Spike Reclaimer Models W139A1-27 All Bulk Spike Trailer Models BSTA1-27
- **SUMMARY:** Inspect the brake chambers (HTT part #192706) for the ability to cage the chambers with the caging tool.
- **OPERATIONAL IMPACT:** The parking / emergency portion of the brake chamber is spring applied and air released. If air system pressure is lost, the spring holds the brake shoe(s) in contact with the wheel. The spring must be mechanically caged to allow the machine to be moved or towed by another machine. A caging tool is provided by the brake chamber manufacturer to mechanically cage the spring.
- ACTION: Inspect the brake chambers to determine if the caging tools can be properly installed. Communicate the requested information to Harsco Track Technologies.
- **CONTACT:** If you have any questions or if we can be of any service, please contact the Service Department at the Columbia, SC. facility, (803) 822-9160.

#### SAFETY INFORMATION



FOLLOW APPLICABLE RAILROAD LOCKOUT - TAGOUT PROCEDURE TO REMOVE ALL ENERGY SOURCES FROM MACHINE. FAILURE TO COMPLY COULD RESULT IN SEVERE BODILY INJURY.

### BRAKE CHAMBER INSPECTION PROCEDURE - See Figure 1 and Figure 2

- 1. Make sure the parking brakes are applied.
- 2. Remove the tethered dust plug from the end of the brake chamber.
- 3. If the caging tool socket appears as shown in Figure 2, record the brake chamber as defective.
- 4. If there is doubt about the alignment of the caging socket, attempt to install the caging tool. If the caging tool cannot properly engage the socket, record the chamber as defective.
- 5. Re-install the dust plug in the end of the brake chamber.
- 6. Repeat Steps 2 thru 5 for each brake chamber on both the Spike Reclaimer and Bulk Spike Trailer.
- 7. Send HTT the following information:

7.1	Spike Reclaimer Model Number
7.2	Spike Reclaimer Serial Number
7.3	Number of defective brake chambers on Spike Reclaimer
7.4	Bulk Spike Trailer Model Number
7.5	Bulk Spike Trailer Serial Number
7.6	Number of defective brake chambers on Bulk Spike Trailer

### **BRAKE CHAMBER INSPECTION PROCEDURE**



FIGURE 1





FIGURE 2 MISALIGNMENT OF CAGING SOCKET IN BRAKE CHAMBER



## THIS PAGE IS INTENTIONALLY BLANK

#### © 2003 HARSCO TRACK TECHNOLOGIES, HARSCO CORPORATION

415 North Main Street Fairmont, MN 56031-1837 Tel: (507) 235-3361 Fax: (507) 235-7370 2401 Edmund Road, Box 20 Cayce-West Columbia, SC 29171-0020 Tel: (803) 822-9160 Fax: (803) 822-7471 200 South Jackson Road Ludington, MI 49431 Tel: (231) 843-3431 Fax: (231) 843-1644

Printed In U.S.A.