

Harsco Track Technologies

Harsco

www.harscotrack.com

CEDVICE DITLETIN

MAINTENANCE OF WAY EQUIPMENT								
DATE:	10-3-2006			BULLETIN NO:	06-008			
TITLE:	FUEL TANK PLATFORM ISOLATION SERVICE GROUP							
RATING:		DIRECTIVE (Action Is Required)	X	ALERT (Potential Problem)				
		INFORMATION (Action Is Optional)		PRODUCT IMPROVEM (Enhance Product)	ENT			
PRODUCT SE	ERIES / M	ODEL: 6700S Tampers						
SERIAL NO:	Models 1	51950 thru 153310, 153356	,153386	6 thru 153391 and 153394				
SUMMARY:	radius on platform t fatigue. T tank from This Serv that all ta Isolation	uel tanks on the above mach the sides of the tank. It has to the edge of the tank is con o mitigate this problem, a So the side platform on the ma rice Bulletin was preceded by nks are to be three point mo Service Group be ordered at Hydraulic Tank Service Gro	been dentributing ervice General America General America General America General America General Gener	etermined that the mounting undue stress to the tank of the solution of the solution of the tank of the solution of the soluti	ng of the and causing clate the commended Fuel Tank con with the			

OPERATIONAL IMPACT: To eliminate fuel tank failure due to platform mounting stress.

ACTION: Follow the Instructions in this Service Bulletin to install the Fuel Tank Platform

Isolation Service Group. Two holes must be drilled through the platform and battery

box cover to install the Service Group.

01-021.

CONTACT: To order the Fuel Tank Platform Isolation Service Group #2012443, contact the

> Parts Department at the Ludington, MI. facility 231-843-3431. If you have any technical questions or if we can be of any service, please contact Mark Krusniak at

the Ludington, MI. facility, 231-843-7415.

SAFETY INFORMATION



n FOLLOW APPLICABLE RAILROAD LOCKOUT - TAGOUT PROCEDURE TO REMOVE MACHINE FROM ENERGY SOURCE. FAILURE TO COMPLY COULD RESULT IN SEVERE BODILY INJURY.

#2012443 SERVICE GROUP INSTALLATION INSTRUCTIONS - See Drawing #2012443

- 1. Remove the existing mounting fasteners between the fuel tank and platform as shown. Discard the mounting fasteners, they will not be re-used.
- 2. Locate the spacer tube (1) per the dimensions shown. Then drill two 1/2" diameter holes in the platform and through the battery box cover as shown so the drilled holes line-up with the spacer tube (1).
- 3. Install the spacer tube (1) between the platform and battery box cover as shown and secure using two 3/8"-16 x 3-3/4" long hex cap screws (2), 3/8"-16 hex lock nuts (3) and 3/8" flat washers (4).
- 4. Install the short spacer (5) and long spacer (6) between the platform and railing as shown and secure using four 3/8"-16 x 1-1/2" long hex cap screws (7), 3/8" lock washers (8) and 3/8" flat washers (4).
- 5. Inspect the mounting fasteners of the fuel tank to the frame. Only three fasteners are to be used to secure the tank to the frame. If four fasteners are present, remove the outside fastener from the rear side of the tank.
- 6. Inspect the mounting fasteners of the fuel tank and hydraulic tank to see if spacer washers are installed between the tank mounting flanges and the frame. If spacer washers are not present, it is recommended to order and install the spacer washers using longer cap screws as stated in Service Bulletin 01-021.

#2012443 SERVICE GROUP PARTS LIST - See Drawing #2012443

ITEM	PART NO	DESCRIPTION	QT	Υ
1	2012444	Spacer - Tube		1
2	250010-116	Screw - Hex Head Cap, 3/8-16" x 3-3/4"		2
3	153140-616	Lock Nut - Grade 5 Hex, 3/8"-16		2
4	158024-4	Washer - Plain Wrought Iron, 3/8"		6
5	2012445	Spacer - Short		1
6	2012446	Spacer - Long		1
7	250010-107	Screw - Hex Head Cap, 3/8"-16 x 1-1/2"		4
8	150988-11	Washer - Regular Lock, 3/8"		4
9	2012443-DWG	Drawing / Bill of Material		1

© 2006 HARSCO TRACK TECHNOLOGIES, HARSCO CORPORATION

415 North Main Street Fairmont, MN 56031-1837 Tel: (507) 235-3361 Fax: (507) 235-7370 2401 Edmund Road, Box 20 Cayce-West Columbia, SC 29171-0020 Tel: (803) 822-9160 Fax: (803) 822-7471 200 South Jackson Road Ludington, MI 49431 Tel: (231) 843-3431 Fax: (231) 843-1644

