

## Harsco

www.harscotrack.com

# CEDVICE BILL ETIM

MAINTENANCE OF WAY EQUIPMENT							
DATE:	12-18-2001			BULLETIN NO:	01-018		
TITLE:	WORKHEAD POSITION CYLINDER ORIFICES SERVICE GROUP						
RATING:		<b>DIRECTIVE</b> (Action Is Required)		ALERT (Potential Problem)			
		INFORMATION (Action Is Optional)	X	PRODUCT IMPROVEME (Enhance Product)	≣NT		
PRODUCT SERIES / MODEL: 6700S TAMPERS							
SERIAL NO:	All Models Serial # 152773 and Higher With All Workhead Position Cartridge Valves In One Manifold						
SUMMARY:	There are times when the workhead position cylinders cannot hold the extended position when the machine is working or traveling down the track. This condition exists when the cylinder is being extended and stopped in mid stroke. An orifice has been added in the rod end hose fitting to eliminate cavitation in the rod end of the cylinder.						
OPERATIONA		T: Improves performance d position cylinders to main	-	minating cavitation, allowin eir position.	g the		

ACTION: The installation of this Service Group requires:

- Disconnecting the hydraulic lines from the workhead position cylinders rod end ports.
- Removing the existing adapter fittings from the cylinders rod end port.
- Installing the new orifice adapter fittings in the cylinders rod end port.
- Reconnecting the hydraulic lines to the new orifice adapter fittings.

If you have any questions or if we can be of any service, please contact Bill **CONTACT:** Perry or Doug Budreau at the Ludington, MI. facility, (231) 843-3431.

#### **SAFETY INFORMATION**




■ FOLLOW APPLICABLE RAILROAD LOCKOUT - TAGOUT PROCEDURE TO REMOVE ALL ENERGY SOURCES FROM MACHINE. FAILURE TO COMPLY COULD RESULT IN SEVERE BODILY INJURY.

#### **SERVICE GROUP INSTALLATION** - See Figure 1

- 1. Disconnect the hydraulic line from the existing adapter fitting (A) in the rod end port of all four workhead position cylinders.
- 2. Remove the existing adapter fitting (A) from the rod end port of all four workhead position cylinders.
- 3. Install a new orifice adapter fitting (1) in the rod end port of all four workhead position cylinders and tighten securely.
- 4. Reconnect the hydraulic line to the new orifice adapter fitting (1) in the rod end port of all four workhead position cylinders and tighten securely.
- 5. Start the engine and pressurize the workhead position cylinders circuit.
- 6. Check the hydraulic lines and new orifice adapter fittings for hydraulic leaks.

## **SERVICE GROUP INSTALLATION**



#### **SERVICE GROUP PARTS LIST**

ITEM	PART NO	DESCRIPTION	QTY
1	2004543	Orifice Adapter Fitting	4

## © 2001 HARSCO TRACK TECHNOLOGIES, HARSCO CORPORATION

415 North Main Street Fairmont, MN 56031-1837 Tel: (507) 235-3361 Fax: (507) 235-7370 2401 Edmund Road, Box 20 Cayce-West Columbia, SC 29171-0020 Tel: (803) 822-9160 Fax: (803) 822-7471 200 South Jackson Road Ludington, MI 49431 Tel: (231) 843-3431 Fax: (231) 843-4830

Printed In U.S.A.