
SERVICE BULLETIN

MAINTENANCE OF WAY EQUIPMENT

DATE: 12 - 2025

BULLETIN NO: SBUS000136-25

TITLE: Replacement instructions for new five-section grinding pump kit for RGH10C4 Rail Grinders.

RATING:

<input type="checkbox"/>	DIRECTIVE (Action Is Required)	<input type="checkbox"/>	ALERT (Potential Problem)
<input type="checkbox"/>	INFORMATION (Action Is Optional)	<input checked="" type="checkbox"/>	PRODUCT IMPROVEMENT (Enhance Product)

PRODUCT SERIES / MODEL: RGH10C4 Rail Grinders

SERIAL NO: N/A

SUMMARY: In response to prior five-section grinding pump drive shaft failures, Harsco Rail now offers a grinding pump replacement kit designed to enhance the strength and reliability of internal pump components.

OPERATIONAL IMPACT:

The five-section grinding pumps included in this replacement kit offer increased robustness compared to those originally supplied with the machine. Earlier pumps and their replacements were susceptible to drive shaft failures caused by elevated hydraulic pressures, particularly when multiple grinding heads lowered simultaneously. Installation of this upgrade kit significantly reduces the likelihood of such failures, improving overall system reliability.

ACTION: Disconnect and remove the existing left and right five-section grinding pumps from the pump drive assembly located behind the engine. Install the components provided in the grinding pump conversion kit. The kit includes all necessary parts for the complete replacement of both five-section grinding pumps.


CONTACT: Harsco Rail Parts Department
1-800-800-6410
Email: railparts@harsco.com

SAFETY INFORMATION



- Follow applicable railroad lockout - tagout procedures to disable energy sources when performing maintenance, making adjustments or repairs to the vehicle or equipment. Failure to heed this warning could result in severe bodily injury.
- Refer to energy control procedure to remove all energy sources from machine before performing maintenance or making adjustments or repairs to machine. Failure to comply could result in severe bodily injury.

Waste Disposal



Dispose of waste properly. Improper disposal of waste can threaten the environment. The operation and maintenance of Harsco Rail equipment may involve the use and disposal of such items as hydraulic fluid, engine oil, coolant, filters, batteries, grinding debris, etc.

Use leak proof containers when draining fluids. Do not pour waste onto the ground, down a drain, or into any water source. Inquire on the proper way to recycle or dispose of waste according to applicable Federal, State and/or Local regulations.

Before Performing Maintenance

1. Make sure the machine is in a safe location for the maintenance being performed.
2. Make sure the maintenance personnel are qualified to perform the maintenance procedures.
3. Apply hand brakes. Chock machine wheels, if required. Make sure unintended movement of the machine cannot occur.
4. Make sure grinding heads and grinding carriages are raised and locked in the stowed position.
5. Stop the engine and turn the master disconnect switch off.
6. Depressurize the air and hydraulic systems.

Grinding Pumps - Disassembly Procedure

1. Close the Ball Valve (A) on each vented relief valve manifold. Ball Valves (qty two) are located on the left and right sides of the engine at floor level. - See Figure 1
2. Close the two Butterfly Valves (B) at the bottom of the hydraulic reservoir. Closing them will isolate the Suction Manifold / Engine Skid. - See Figure 2

FIGURE 1
RH VENTED RELIEF VALVE MANIFOLD - BALL VALVE
(LH Side Similar - Ball Valve Shown in OPEN Position)






FIGURE 2
HYDRAULIC RESERVOIR - BUTTERFLY VALVES
(Shown in CLOSED Position)



3. Locate and open the two Suction Manifold /Engine Skid Drains. Drain hydraulic fluid into a clean, properly-sized leak-proof container by turning the ball valve handles parallel to the valve body. - See Figure 3
4. Shut the two ball valves—ensuring the handles are perpendicular to the valve body—once the fluid has adequately drained from the Suction Manifold / Engine Skid Drains.
- See Figure 3

FIGURE 3
GRINDING PUMPS - DISASSEMBLY



5. Disconnect all fittings attached to the existing five-section grinding pump. Place split flange fittings and hardware in a safe place for re-use later. - See Figures 3 and 4
6. Support the five-section grinding pump prior to removing mounting hardware.
- See Figure 5
7. Remove the fasteners securing the existing pump brackets to the engine skid, and the fasteners mounting the five-section grinding pump to the pump drive. - See Figure 5
8. Fully loosen all suction hose clamps where they attach to the Suction Manifold / Engine Skid.
9. Slowly lift and move the five-section grinding pump, pump bracket and suction hoses away from the pump drive and suction manifold / engine skid.
10. Repeat the steps above for the other grinding pump removal.

FIGURE 4
REMOVE HYDRAULIC FITTINGS AT PUMP





FIGURE 5
REMOVE FASTENERS



Grinding Pumps - Assembly Procedure - See Figures 6 and 7

Note: Refer to the figures and Engineering Print 5151588 for the Permco Grind Pump Conversion Kit.

1. Apply O-Ring Lubricant (13) to two new O-Rings (12) and place them into the two grooves on the bottom side of Grinding Pump (3).
2. Apply Loctite 242-Blue (14) to threads of Skt Hd CS 1/2-13X1 1/2 (18).
3. Mount two Offset Manifolds (10) onto the bottom ports of new Grinding Pump (3) as shown. Secure with Washer, Lock, 1/2", High Collar (17) and Skt Hd CS 1/2-13X1 1/2 (18). Torque as specified in Operator's Manual - Appendix A.

Note: Ensure that the Offset Manifold will be properly aligned with the engine skid tube nipple when installed. See Engineering Print 5151588.

4. Install two new Hose, Suction (20) onto the Offset Manifold (10) and secure with two new Clamps (19). Slide two more Clamps (19) onto the each Hose (20) and tighten just enough so they don't fall off - they'll be tightened fully later when mounting onto the engine skid.
5. Apply G-N Metal Assembly Paste (15) to the splines of Grinding Pump (3).
6. Apply O-Ring Lubricant (13) to O-Ring (2) prior to installing into the groove on the end of Grinding Pump (3).
7. Apply Silicone Gasket Maker (16) to Grinding Pump (3) and pump drive mating faces.
8. Support Grinding Pump (3) for installation and slide the splined end into matching splines on Pump Drive.
9. Apply Loctite 242-Blue (14) to threads of four Hex Flange Head Cap Screws 1/2-13X1-1/4 GR5 (11).
10. Secure the pump to the Pump Drive with the four Hex Flange Head Cap Screws (11). Torque as specified in Operator's Manual - Appendix A.
11. Mount new Pump Support Weldment (1) to Five-Section Grinding Pump (3) using Washer, Flat, M16, DIN125, YZP (6) and Lock Nut Nylon, M16 x 2.0 (7).
 - a. Slide two Washers (6) onto both long pump studs to act as spacers.
 - b. Mount the Pump Support Weldment (1) onto the Grinding Pump (3).
 - c. Add one more Washer (6) to each stud.
 - d. Secure everything with nylon lock nuts (7), but do not tighten yet.
12. Line up the holes in the Pump Support Bracket (1) with the matching holes in the Engine Skid Weldment. Secure using the following fasteners:
 - a. Hex Flange Bolts M12×1.75×40 (9).
 - b. 1/2" Hardened Flat Washers (8).
 - c. Hex Flange Nuts M12×1.75 (5)

13. Tighten all Pump Support Bracket (1) fasteners to the torque specified in Appendix A of the Operator's Manual.
14. Apply O-Ring Lubricant (13) to five new O-Rings (4) and place them into the five grooves in the top side of Grinding Pump (3).
15. Connect the five Split Flange kits (for the 90° fittings) with the matching ports on the top side of the Grinding Pump (3). Attach the flange kits using the original fasteners. Torque as specified in Operator's Manual - Appendix A.
16. Repeat steps for installing the Five-Section Grinding Pump (3) for the opposite side.

FIGURE 6
GRINDING PUMPS - ASSEMBLY





FIGURE 7
GRINDING PUMPS - ASSEMBLY



After Installation Procedure

1. After installation is complete, re-open any valves closed during the hydraulic reservoir isolation procedure.
2. Make sure the two ball valve drains on the Suction Manifold / Engine Skid are closed.
3. Check for hydraulic fluid leaks and repair as necessary.
4. Check the Hydraulic Reservoir fluid level and re-fill it as needed. Refer to Operator's Manual - Section 4 - Maintenance for reservoir level checking and reservoir filling procedures.
5. Start up the machine to pressurize hydraulic system, check for hydraulic leaks and address as needed.
6. After grinding operations have resumed, periodically check hydraulic reservoir fluid level and check for leaks and address as needed.

Permco Grind Pump Conversion Kit - (see 5151588 print for illustration)

ITEM	PART NO	DESCRIPTION	QTY
	5151588	PERMCO GRIND PUMP CONVERSION KIT, C4	
1	5152996	PUMP SUPPORT BRACKET	2
2	F040724	O-RING, 4 X 3/32, NBR 70 DURO	2
3	5150279	PUMP, GEAR, 5-SECTION, 29CC	2
4	F014738	O-RING	10
5	F041200	HEX FLG NUT M12X1.75 ZP	4
6	A0069048	WASHER, FLAT, M16, DIN125, YZP	12
7	252050-11	LOCK NUT, NYLON, M16 X 2.0	4
8	F023222	WASHER, FLAT, 1/2", HARDENED	4
9	408784	HEX FLG CS M12X1.75X40 CL8	4
10	5153000	OFFSET MANIFOLD	4
11	F022036	HHD CAP SCR1/2-13X1-1/4GR5	8
12	F014609	O RING 2 3/4 X 3 X 1/8	4
13	F013756	O RING LUBRICANT	1
14	F015774	LOCTITE-242 BLUE	1
15	5151216	G-N METAL ASSEMBLY PASTE, 2.8 FL. OZ. TUBE	1
16	L425072	SILICONE GASKET MAKER	1
17	150988-13	WASHER, LOCK, 1/2", HIGH COLLAR	16
18	F011713	SKT HD CS 1/2-13X1 1/2	16
19	F041580	CLAMP	16
20	5152078	HOSE, SUCTION (-40)	4

FACILITY LOCATIONS

HARSCO RAIL, LLC

306 West Fourth Street
Fairmont, MN
56031-1837
Tel: +1 (507) 235-7376
Parts: +1 (800) 800-6410
Fax: +1 (507) 235-7372

HARSCO RAIL, LLC

2401 Edmund Road, Box 20
Cayce-West Columbia, SC
29171-0020
Tel: +1 (803) 822-7420
Parts: +1 (800) 800-6410
Fax: +1 (803) 822-7403

HARSCO RAIL, LLC

200 South Jackson Road
Ludington, MI
49431
Tel: +1 (231) 843-3431
Parts: +1 (800) 800-6410
Fax: +1 (231) 843-1644

**HARSCO RAIL
GLOBAL HEADQUARTERS**

3440 Toringdon Way
Suite 107, Building 3
Charlotte, NC 28277
56031-1837
Tel: +1 (980) 960-2624

HARSCO RAIL, LTDA

Av. Marechal Câmara
160 / 1615, Centro
Rio de Janeiro RJ 20020-080
Brazil
Tel: +55 21 2510-5164 / -5151

HARSCO RAIL EUROPE, GmbH

Luetticher Str. 130
40547 Duesseldorf, Germany
Tel: +49 (0) 211 60116 0

HARSCO RAIL CHINA

Room C1201 Tower 2,
No.36 BeiSanHuan Dong Lu,
DongCheng District,
Beijing 100013, P.R. China
Phone: +87 10-6590-6399

**HARSCO TRACK MACHINES AND
SERVICES PRIVATE**

Limited India
2nd Floor, Building Alpha,
Bengal Intelligent Park Block EP &
GP,
Sector V, Salt Lake, Kolkata
700091 West Bengal, India
Phone: +91 33 2357 5651

HARSCO RAIL MALAYSIA



3-5, Block A, Jaya One
72A Jalan Profesor Diraja Ungku
Aziz,
46200 Petaling Jaya,
Selangor, Malaysia

HARSCO RAIL LTD



Unit 1 Chewton Street
Eastwood, Nottingham, NG16 3HB
United Kingdom
Tel: +44 (0) 1773 539480

HARSCO RAIL PTY LTD

157 Granite St
Geebung, Queensland 4034
Australia
Tel: 61 7 3205 6500
Fax: 61 7 3205 7369



DISCONNECT SUCTION & PRESSURE HOSES
REMOVE EXISTING 5-SECTION PUMP
& REAR SUPPORT BRACKET



INSTALL 2 WASHERS ON BOTH LONG PUMP STUDS
PRIOR TO ATTACHING REAR PUMP SUPPORT BRACKET.

DETAIL A

ITEM	PART NO	QTY	DESCRIPTION	ITEM	PART NO	QTY	DESCRIPTION
17	I50988-13	16	WASHER, LOCK, 1/2", HIGH COLLAR	1	5152996	2	PUMP SUPPORT BRACKET
18	F0II713	16	DC-SKT HD CS 1/2-I3XI 1/2	2	F040724	2	O-RING, 4 X 3/32, NBR 70 DURO
19	F041580	16	CLAMP	3	5150279	2	PUMP, GEAR, 5-SECTION, 29CC
20	5152078	4	HOSE, SUCTION (-40)	4	F014738	10	O-RING
				5	F041200	4	DC-HEX FLG NUT MI2XI.75 ZP
				6	A0069048	12	WASHER, FLAT, M16, DIN125, YZP
				7	252050-II	4	LOCK NUT, NYLON, M16 X 2.0
				8	F023222	4	WASHER, FLAT, 1/2", HARDENED
				9	408784	4	DC-HEX FLG CS MI2XI.75X40 CL8
				10	5153000	4	OFFSET MANIFOLD
				11	F022036	8	DC-HHD CAP SCR/2-I3XI-1/4GR5
				12	F014609	4	O RING 2 3/4 X 3 X 1/8
				13	F013756	1	DC-O RING LUBRICANT
				14	F015774	1	LOCTITE-242 BLUE
				15	5151216	1	G-N METAL ASSEMBLY PASTE, 2.8 FL. OZ. TUBE
				16	L425072	1	SILICONE GASKET MAKER

NOTES:

REFER TO OPERATION & MAINTENANCE MANUAL FOR GENERAL SAFETY AND ENERGY CONTROL PROCEDURES.

TO PREVENT EXCESSIVE FLUID LOSS DURING DISASSEMBLY, REFER TO THE OPERATION & MAINTENANCE MANUAL FOR HYDRAULIC RESERVOIR ISOLATION PROCEDURE.

USE MOLYKOTE METAL ASSEMBLY PASTE (IT. 15) TO COAT NEW PUMP SPLINES PRIOR TO MOUNTING TO PUMP DRIVE.

USE SILICONE GASKET MAKER (IT. 16) ON PUMP MOUNTING FACES PRIOR TO MOUNTING TO PUMP DRIVE.

THE SUCTION AND PRESSURE PORTS FOR THE NEW PUMPS ARE IN SLIGHTLY DIFFERENT LOCATIONS, THEREFORE SOME HOSE ADJUSTMENTS MAY BE NECESSARY.

REPLACE ANY DAMAGED O-RINGS, USE O-RING LUBE (IT. 13) TO LUBRICATE ALL O-RINGS DURING RE-ASSEMBLY.

LOCTITE ALL PUMP MOUNTING BOLTS WITH LOCTITE 242 BLUE (IT. 14).

TORQUE ALL FASTENERS PER MAINTENANCE MANUAL STANDARDS.

AFTER INSTALLATION IS COMPLETE, RE-OPEN ANY VALVES CLOSED DURING HYDRAULIC RESERVOIR ISOLATION PROCEDURE.

CHECK FOR HYDRAULIC LEAKS AND ADDRESS AS NEEDED.

CHECK HYDRAULIC RESERVOIR FLUID LEVEL AND ADD AS NEEDED. REFER TO OPERATION & MAINTENANCE MANUAL FOR HYDRAULIC RESERVOIR FILLING PROCEDURE.

START UP MACHINE TO PRESSURIZE HYDRAULIC SYSTEM, CHECK FOR HYDRAULIC LEAKS AND ADDRESS AS NEEDED.

AFTER GRINDING OPERATIONS HAVE RESUMED, PERIODICALLY CHECK FOR ANY HYDRAULIC LEAKS AND ADDRESS AS NEEDED.

Inch
[mm]

CONFIDENTIAL

COPYRIGHT 2025 HARSCO RAIL, LLC, ALL RIGHTS RESERVED. THIS DRAWING OR DOCUMENT IS THE PROPERTY OF HARSCO RAIL AND EMBODIES CONFIDENTIAL INFORMATION, TRADE SECRET INFORMATION, AND/OR KNOW-HOW THAT IS THE PROPERTY OF HARSCO RAIL. BY ACCEPTING THIS DRAWING OR DOCUMENT, THE RECIPIENT AGREES (1) NOT TO PROVIDE, OR OTHERWISE MAKE AVAILABLE, THE DRAWING OR DOCUMENT, OR ANY INFORMATION OR KNOW-HOW EMBODIED THEREIN, TO ANY THIRD PARTY AND (2) NOT TO REPRODUCE OR USE THE DRAWING OR DOCUMENT TO MANUFACTURE ANY APPARATUS OR DEVICE, WITHOUT THE PRIOR WRITTEN AUTHORIZATION OF HARSCO RAIL.

FEATURES ENCLOSED IN C			ARE KEY CHARACTERISTICS			UNLESS OTHERWISE SPECIFIED:		
NOMINAL SIZE RANGE	INCH	PLUSE OR MINUS	NOMINAL SIZE RANGE	METRIC	PLUSE OR MINUS	1 PLACE DECIMAL	2 PLACE DECIMAL	ANGULAR TOLERANCE OF .50° CONCENTRICITY WITHIN .010
OVER TO	2 PLACE DECIMAL	3 PLACE DECIMAL	OVER TO	1 PLACE DECIMAL	2 PLACE DECIMAL			ALL MACHINED SURFACES WILL HAVE: A MAXIMUM SURFACE FINISH OF 125 UNITS ANGULAR TOLERANCE OF .50° CONCENTRICITY WITHIN .010
0 6	.03	.005	0 150	.8	.13			3. ALL WELDS SHOULD BE MADE TO THE MOST CURRENT WELDING STANDARDS
2X 10			3X 19					4. TORQUE ALL FASTENERS PER STD-1603D
4X 19			20					5. TORQUE ALL FITTINGS PER STD 5369
2X 12			3X 19					
4X 19			20					
4X 19			20					
4X 19			20					

1. REMOVE BURRS AND BREAK SHARP EDGES
2. ALL MACHINED SURFACES WILL HAVE:
A MAXIMUM SURFACE FINISH OF 125 UNITS
ANGULAR TOLERANCE OF .50°
CONCENTRICITY WITHIN .010
3. ALL WELDS SHOULD BE MADE TO THE MOST
CURRENT WELDING STANDARDS
4. TORQUE ALL FASTENERS PER STD-1603D
5. TORQUE ALL FITTINGS PER STD 5369

THIRD ANGLE PROJECTION
DRAFTED PER HARSCO RAIL STANDARD
STD-1601D

CHANGE	R/L	REVISION	DR	DATE	Description
EC621923	A	NEW RELEASE	RTM	11/21/25	PERMCO GRIND PUMP CONVERSION KIT, C4

Material	Machine Type	Size
	RGH10C4	C

Weight	Drawn	Date Drawn	Part Number
	RMEYER	11/21/2025	5151588

SOLID EDGE DRAWING	DO NOT SCALE
--------------------	--------------

HARSCO
RAIL
Sheet
1 of 1