

# Product Improvement

Mark IV Clark Transmission

Part # D4664Y02 -New

Part # D4664Y02EX - Exchange

## Clark Transmissions for Mark IV Production/Switch Tampers, New and Exchange

### Summary

Harsco Rail supplies Clark transmissions for Mark IV Production/Switch Tampers, New and Exchange. As a leading supplier of surfacing equipment in the North American market, Harsco Rail Clark transmissions provide supreme quality with expedited service. New and Exchange units and repair parts are in stock and ready to ship. Minimize your machine downtime with OEM parts.



### Benefits:

- Off-the-shelf delivery
- OEM Quality
- Improved machine lifetime
- Expedited service



2401 Edmund Road  
West Columbia, SC 29171 USA  
Tel: (803) 822-9160 Fax: (803) 822-8107  
Email: [railparts@harsco.com](mailto:railparts@harsco.com)  
[www.harscorail.com](http://www.harscorail.com)

**HARSCO**  
RAIL

# Product Improvement

Mark IV Clark Transmission

Part # D4664Y02 -New

Part # D4664Y02EX - Exchange

## Clark Transmission Repair Parts

P/N	DESCRIPTION	P/N	DESCRIPTION
5046980	GASKET	5047206	FITTING
5046982	INPUT SHAFT	5047207	O RING
5046983	OUTPUT SHAFT	5047209	LOCKWASHER
5046984	SCREW - SCREEN	5047210	COVER PLATE
5046995	CAP - PLUG #14	5047212	PLUG
5046996	BUSHING	5047213	SNAP RING
5047002	SHIM	5047214	PLUG
5047006	CAE NAME PLATE	5047215	SPACER
5047007	PLUG	5047216	SNAP RING
5047008	EXPANSION PLUG	0-3350000-0-05	FILTER, TRANSMISSION
5047009	TRANSMISSION CASE	D8489P01	SEAL-OIL
5047010	PLUG	D8489P03	BEARING-BALL
5047011	CAP\$CREW M8X75LE	D8489P04	BEARING-ROLLER
5047069	WASHER	D8489P05	CAP-OUTPUT SHAFT FRT BRG
5047070	WASHER	D8489P08	GEAR-OUTPUT SHAFT, 59T
5047079	WASHER	D8489P11	PISTON-RING
5047098	WASHER	D8489P12	PISTON-RING
5047099	WASHER	D8489P13	PISTON-RING
5047101	WASHER	D8489P14	GEAR-INPUT SHAFT, 19T
5047102	SHIM	D8489P15	GEAR-INPUT SHAFT CLUTCH,
5047103	SHIM	D8489P16	BEARING-TAPER ROLLER
5047119	SHIM	D8489P17	BEARING-NEEDLE ROLLER
5047121	SHIM	D8489P18	DISC-CLUTCH OUTER
5047122	SHIM	D8489P19	DISC-CLUTCH INNER
5047123	SHIM	D8489P21	DISC-CLUTCH PISTON
5047124	SHIM	D8489P22	SLEEVE-CLUTCH PISTON
5047126	SHIM	D8489P23	PISTON-CLUTCH
5047128	SHIM	D8489P24	HUB-CIUTCH
5047133	SHIM	D8489P25	BEARING-TAPER ROLLER
5047135	SHIM	D8489P26	CAP-INPUT SHAFT BEARING
5047136	PIN	D8489P28	PISTON RING
5047137	SCREW	D8489P29	PISTON RING
5047140	SCREW	D8489P30	PISTON RING

2401 Edmund Road  
West Columbia, SC 29171 USA  
Tel: (803) 822-9160 Fax: (803) 822-8107  
Email: railparts@harsco.com  
www.harscorail.com

**HARSCO**  
RAIL

# Product Improvement

Mark IV Clark Transmission

Part # D4664Y02 -New

Part # D4664Y02EX - Exchange

## Clark Transmission Repair Parts

P/N	DESCRIPTION	P/N	DESCRIPTION
5047142	SCREW	D8489P31	GEAR-INTERMEDIATE SHAFT,
5047143	SCREW	D8489P32	GEAR-INTERMEDIATE SHAFT,
5047151	SCREW	D8489P33	AS5Y-BEARING
5047153	SCREW	D8489P34	BEARING-NEEDLE ROLLER
5047154	SCREW	D8489P35	RING - BEARING INNER
5047155	SCREW	D8489P36	SHAFT-INTERMEDIATE
5047156	SCREW	D8489P37	DISC-CLUTCH PISTON
5047157	PLUG	D8489P38	SLEEVE-CLUTCH PISTON
5047163	SCREW	D8489P39	PISTON-CLUTCH
5047167	CAPSCREW	D8489P40	HUB-CLUTCH
5047175	CAP5CREW	D8489P41	DISC-CLUTCH OUTER
5047177	HOLE PLUG	D8489P42	DISC-CLUTCH INNER
5047181	PLUG	D8489P43	NUT-INTERMED. SHAFT BRG
5047182	SEAL, O RING	D8489P44	GEAR-INTERMEDIATE SHAFT,
5047183	COVER, REAR	D8489P45	BEARING-TAPER ROLLER
5047185	SHIM	D8489P46	CAP-INTERMED. SHAFT BRG
5047186	SHIM	D8489P47	BREATHER-AIR
5047187	SHIM	D8489P48	SPRING-SUCTION SCREEN
5047190	COVER	D8489P49	SCREEN-SUCTION
5047191	COVER	D8489P51	O-RING
5047192	SPACER	D8489P52	FLANGE-OUTPUT
5047193	SPRING	D8489PS4	SHIELD-DUST
5047194	DISC	D8489P55	NUT-OUTPUT SHAFT
5047195	SPRING	D8489P56	O-RING
5047196	COVER CAP	D8489P58	SLEEVE-PISTON RING
5047198	DISC	D8489P59	SLEEVE-PISTON RING
5047199	PLATE	D8489P60	ADPTR-HYDROSTATIC MOTOR
5047200	PLATE	D8489P61	PLATE-VALVE ADAPTER
5047201	SPACER	D8489P64	ASSY-CONTROL VALVE
5047202	RING	D8489P65	O-RING
5047203	SPACER	D8489P66	5LEEVE-HYDR. MOTOR INPUT
5047204	FITTING	D8489P70	FILTER FITTING

2401 Edmund Road  
West Columbia, SC 29171 USA  
Tel: (803) 822-9160 Fax: (803) 822-8107  
Email: railparts@harsco.com  
www.harscorail.com

**HARSCO**  
RAIL