

TRACK RENEWAL SYSTEM

Model TRT-909



HARSCO
RAIL
Insight onsite.™

TRACK RENEWAL SYSTEM

Special Features

Harsco Rail's TRT-909 track renewal system provides a more efficient method to handling major track renewal programs. The TRT-909 works with concrete, pre-plated wood, or steel ties. It delivers simplicity in operation for customers and leaves behind high quality track with precise tie spacing and a smooth ballast bed.

Features & Benefits

- Works with concrete, pre-plated wood, or steel ties
- Removes and replaces crossties
- Pulls and reclaims spikes
- Removes and collects rail anchors
- Removes the old rail and installs the new rail
- Induction Rail Heaters
- Automatically applies McKay rail fasteners (other types of fasteners can be applied)
- Vacuum System





Spike Pullers

Spike pullers remove the field side spikes and leave the gauge side spike to hold the tie plate in a fixed position. There is one spike puller located over each rail. A magnetic spike pick-up wheel reclaims the spikes after they have been pulled.

Old Tie Equipment

The old crossties are lifted from the roadbed and placed on the conveyor by the Old Tie Pick-Up Mechanism. The old ties are then transported by conveyors to a staging area where a gantry collects them for transport to storage areas on the flatcars.

Roadbed Preparation

Immediately behind the Old Tie Pick-Up Mechanism, a ballast spreader/plow destroys the old tie molds and undercuts the ballast section to prepare the roadbed for the new ties.

New Tie Laying

The new ties are then positioned on the prepared roadbed by the New Tie Laying Mechanism. A tie spacer bar squares up the crossties after they are laid on the track bed. A distance counter wheel controls the spacing of the ties and is adjustable to meet various tie spacing requirements.

Rail Laying/Threading

Using a series of rollers, the old rail is removed and threaded out along side of the track, and the new rail is picked up from the shoulder and laid in gauged position. Thus, the machine simultaneously removes the old rail while laying the new rail.

Gantries

Each self-propelled gantry has one operator. The rear gantries transport ties to and from the front gantry which in turn moves the ties to and from the old and new tie conveyors.

Flat Cars

Standard flat cars are equipped with auxiliary rails which form a continuous running rail for the gantries. The flat cars are stocked with new ties in four or five layers. As new ties are used, old ties are stored on the flat cars.

Induction Rail Heater

The Induction Rail Heater provides accurate and efficient rail distressing capability. The heaters raise the rail temperature to the required neutral temperature.

Contract Services

The first track renewal system was built in 1978 and has since installed approximately 15,000,000 ties (equal to 5,700 miles or 8,500 km). Harsco Rail's Contract Services provide customers with a high quality service by crews that know the machine's maintenance and operation best.

TRACK RENEWAL SYSTEM

Specifications

Length	Without Locomotive: 90.2 m (296 ft.)
Width	On Bogie: 3.24 m (10 ft., 8 in.)
Height	4.72 m (15 ft., 6 in.)
Drive Train	525 hp diesel driving variable-flow hydraulic pumps for hydrostatic advance of the machine during work. Three (3) variable-flow hydraulic pumps supplying the Old Tie Pick-up System and the Rail Guide System.
Traction during Operation	6 powered bogies
Min Curve Radius	(Working) 144 m (12 degrees) (478 ft.) (Traveling) 97.5 m (18 degrees) (320 ft.)
Ballast Regulation	Over a width of about 2.79 m (110 ft.)
Plow Height Adjustment	152.4 mm (6 ft.)
Plow Traverse Inclination	(Change in cross level) 38 mm (1 ft., 6 in.)
Max Length of Ties Handled	2.81 m (9 ft., 3 in.)
Traveling Speed	Towed: Up to 80 km/h (50 mph)
Operator's Stations	Five (5)
Fuel Capacity	2,082 liters (550 gal.)
Hydraulic Oil Capacity	1,741 liters (460 gal.)
Distance between Axles/Bogies	13.80 m (45 ft., 3 in.) / 17.53 m (57 ft., 6 in.)
Brakes	Compressed air shoe brakes, hand brake with wheel control
Guide Rail Correction	±75mm (±2.95 ft.)
Gantries	
Length	8.58 m (28 ft., 2 in.)
Width	3.10 m (10 ft., 2 in.)
Height	3.10 m (10 ft., 2 in.)
Gauge of Auxiliary Rail	2.92 m (115 5/16 in.)
Capacity	18-22 sleepers
Fuel Capacity	379 liters (100 gal.)

Download full specs at www.hascorail.com
Watch video at www.youtube.com/user/hascorail

Harsco Rail Global Headquarters

3440 Torrington Way
Suite 100, Building 3
Charlotte, NC 28277, USA

Main Tel: +1 803 822-9160
Email: railinfo@hasco.com
www.hascorail.com

HARSCO
RAIL



Bulletin #S-01B-0116
Updated in USA, September 2018

Harsco Rail, Harsco Corporation Facility Locations:

Harsco Rail Global Headquarters
3440 Torrington Way
Suite 100, Building 3
Charlotte, NC 28277, USA
Tel: +1 980 960-2624
E-Mail: railinfo@hasco.com

Harsco Rail Manufacturing Operations
2401 Edmund Road, Box 20
West Columbia, SC 29171-0020, USA
Tel: +1 803 822-9160
E-Mail: railinfo@hasco.com

Harsco Rail Engineering Center
306 West 4th Street
Fairmont, MN 56031-1837, USA
Tel: +1 507 235-7376
E-Mail: railinfo@hasco.com

Harsco Rail Manufacturing Operations
200 South Jackson Road
Ludington, MI 49431, USA
Tel: +1 231 843-3431
E-Mail: railinfo@hasco.com

Protran Technology
1960 Old Cuthbert Road
Suite 100
Cherry Hill, NJ 08034, USA
Tel: +1 856 779-7795
E-Mail: info@protrantech.com

Harsco Rail Pty Ltd Australia
4 Strathwyn Street, P.O. Box 5287
Brendale
Queensland 4500, Australia
Tel: +61 7 3205 6500

Harsco Rail Ltd United Kingdom
Unit 1, Chewton Street, Eastwood
Nottingham NG16 3HB, United Kingdom
Tel: +44 (0) 1773 539480
Email: uksales@hasco.com

Harsco Rail Ltda Brazil
Av. Marechal Câmara, 160 / 1615,
Centro
Rio de Janeiro RJ 20020-080, Brazil
Tel: +55 21 2510-5164 / -5151

Harsco Rail Europe GmbH
Luetticher Str. 130
40547 Duesseldorf, Germany
Tel: +49 (0) 211 60116 0
E-Mail: info@hasco-r.de

Harsco Rail China
Room C1201 Tower 2,
No.36 BeiSanHuan Dong Lu,
DongCheng District,
Beijing 100013, P.R. China
Tel: +87 10-6590-6399

Harsco Track Machines and Services
Private Limited India
2nd Floor, Building Alpha,
Bengal Intelligent Park Block EP & GP,
Sector V, Salt Lake, Kolkata
700091 West Bengal, India
Tel: +91 33 2357 5651

The HARSCO RAIL equipment pictured in this brochure is intended to illustrate the general appearance and features of this product. It is equipped as specified by a particular customer and may or may not show items that are optional or recommended by HARSCO RAIL, Harsco Corporation. Specifications, illustrations, and descriptive materials herein were accurate as known at the time this publication was approved for printing. HARSCO RAIL, Harsco Corporation reserves the right to discontinue models or options at any time or change specifications and materials, equipment and design without notice and without incurring obligation. Federal, State or Provincial, and/or local laws and regulations may require additional equipment for the particular use intended for this product. It is the buyer's responsibility to determine the applicability of such laws and regulations to the buyer's intended use for the product and to arrange for the installation of the required equipment. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies and/or mark holders.